

IPC Electronics Midwest 2010

Graham Naisbitt



Gen3 Systems Limited

Look out SIR! SIR Test Results and Misleading Data

Biography:

Managing Director

Over 30 years in the electronics industry, a specialist in conformal coating, cleaning, SIR & CAF, electro-chemical issues, solderability and process control matters. Vice or Co-Chairman of several standards committees with IPC, IEC and BSi, also offering consultancy services.

Contact Info:

Mr. Graham K. Naisbitt
Unit B2, Armstrong Mall
Southwood Business Park
Farnborough, Hampshire GU14 0NR
United Kingdom
W: +44 12 5252 1500
graham.naisbitt@gen3systems.com

Look out SIR!


SIR Test Results and Misleading Data

IPC Midwest
Chicago
September 2010

Look-out SIR!

- Mistakes are costly!

Cost of repairing mistakes increases roughly by an order of magnitude at each stage



Courtesy of Harvard Business School ("Business Week" Magazine)



CANON COMMUNICATIONS LLC

Association Connecting Electronics Industries



Look-out SIR!

- The most commonly asked question:
If I am going to apply a conformal coating do I have to clean?
- Short answer - probably
- Long answer - it depends*....

*Appears courtesy of Doug Pauls



CANON COMMUNICATIONS LLC

Association Connecting Electronics Industries



Look-out SIR!

Ask yourself:

- ...Are you sure you have your process under control?
- ...Are you sure that your process chemistries are electro-chemically compatible?
- ...Do you know the answer to “How Clean is Clean?”



CANON COMMUNICATIONS LLC

Association Connecting Electronics Industries



Look-out SIR!

This question has been around since Adam was a boy!

- In the 1970's the US Military and our (British) DOD decided to put a stake in the ground:
 - That stake remains to this day, but at a level of $<1.5\mu\text{g}/\text{cm}^2$ NaCl equivalence...
 - This measurement involves a quick and easy process control called ROSE or SEC testing



CANON COMMUNICATIONS LLC




Association Connecting Electronics Industries




Look-out SIR!

- ROSE / SEC is a measure of ionic contamination that would cause electro-chemical reactions provided that 3 elements are present:
- Humidity
- Ionics
- Electrical bias




Look-out SIR!

Monolayer of water (liquid)




Elevated Humidity/Condensation =
Generally OK

Ionic Contamination



Normal Conditions = OK

Electrolyte



Elevated Humidity = Electrolytic Cell





CANON COMMUNICATIONS LLC

Association Connecting Electronics Industries



Look-out SIR!


- The major limitations of this test are:
- $<1.5\mu\text{g}/\text{cm}^2$ means its OK to leave UP TO that amount of NaCl on every square cm of your assembly! Are you sure?
- Averaged over the area but the problem might be localised
- It can only detect ionics - what about non-ionics?



Look-out SIR!

ROSE Testing – Advantages:


- A fast test - 5 to 15 minutes
- Can be run by unskilled operators
- A superb process control tool
- Cheap as chips



Look-out SIR!

Is there another way?

- Yes. Ion Chromatography (IC)
- BUT: At this point someone with an IQ >120 is required!



Look-out SIR!

Ion Chromatography (IC)

- IC is based on the use of specialised column packing for separation of ions
- An analytical technique used to separate, identify, and quantitate ions in a sample matrix
- Separating ions due to their different size, polarity, ionic strength, and affinity to stationery phase



CANON COMMUNICATIONS LLC



Association Connecting Electronics Industries



Look-out SIR!

Ion Chromatography - Limitations:

- Requires highly skilled operators
- Expensive to run
- Time to run test is a lot more than 15 minutes!



Association Connecting Electronics Industries



CANON COMMUNICATIONS LLC




Look-out SIR!

Ion Chromatography - Limitations:

Ion Chromatography will tell you exactly what is on the surface under test -


- it will NOT tell you whether the end product will be reliable.



Look-out SIR!

Ion Chromatography - Advantages

- Highly accurate
- Excellent species differentiation
- Can be employed for localised contamination
- Looks impressive to the visiting customer!



Look-out SIR!

...Is there another way?

- Yes. FTIR - Fourier Transform Infrared Spectroscopy
- AKA - Frustrated Total Internal Reflection!
- At this point someone with an IQ >140 is required!



CANON COMMUNICATIONS LLC

Association Connecting Electronics Industries



Look-out SIR!

FTIR - Fourier Transform Infrared Spectroscopy -

- ...is a measurement technique whereby spectra are collected based on measurements of the temporal coherence of a radiative source, using time-domain measurements of the electromagnetic radiation or other type of radiation.

•Thank-you Wikipedia!



Look-out SIR!

...and the other way?

SIR = Surface Insulation Resistance

The principal:

- An inter-digitated test pattern
- Electrical bias
- Measuring the degradation or changes of surface insulation resistance





CANON COMMUNICATIONS LLC

Association Connecting Electronics Industries



Look-out SIR!

- SIR Testing will tell you if the end product will be electro-chemically reliable, but it won't tell you what it is that is causing a failure.



Look-out SIR!

New SIR test standards have been published that facilitate Process Characterisation Testing:

- IEC 61189-5 Method 5E02
- IPC-TM-650 2.6.3.7

And under consideration:

- IPC-9202
- IPC-9203




CANON COMMUNICATIONS LLC

Association Connecting Electronics Industries



Look-out SIR!

- What is involved?
 - A test coupon (IPC-B52 as shown or IEC-TB57)
 - A test chamber capable of providing well controlled heat and humidity
 - A precision measuring system
 - Interconnecting cables
 - Data collection and graphical interpretations





CANON COMMUNICATIONS LLC

Association Connecting Electronics Industries



Look-out SIR!

- It's not as hard as you might think and easier than it used to be
 1. Select your process suppliers - board and finishes
 2. Purchase the kits of dummy components
 3. "Process" the coupons as per the end product
 4. Place into the test rack
 5. Turn on the chamber
 6. Sit back and relax for at least 72 hours!



Association Connecting Electronics Industries




CANON COMMUNICATIONS LLC




Look-out SIR!

- Results?
 - These are good results:

- At start of test



- At end of test




CANON COMMUNICATIONS LLC



onics Industries


Look-out SIR!

- Results?
 - These are good results:



Look-out SIR!

- Results?
 - Pass or Fail? You decide:




CANON COMMUNICATIONS LLC

Association Connecting Electronics Industries




Look-out SIR!

- Results?
 - Failures look like this:




Look-out SIR!

- Results?
 - If you see this, it might mean longer term





Look-out SIR!

- Results?
 - If you see this. check the connections!




Look-out SIR!

- Results?
 - If you see this before you test, you have a “poisoned” chamber




Look-out SIR!

- Results?
 - If you see this, check the water supply to the chamber




Look-out SIR!

- Results?
 - The difference between 40°C 90%RH and 85°C




Look-out SIR!

- Results?
 - Compare IPC B52 with IEC TB57 & 85/85 v 40/90




Look-out SIR!

- Results?
 - Compare IPC B52 with IEC TB57 & 85/85 v 40/90




Look-out SIR!

- Results?
 - Effect of solder resist – IPC B52 bare coupon




Look-out SIR!

- Results?
 - Effect of solder resist – IEC TB57 bare coupon




Look-out SIR!

- Results?
 - The effect of capacitance




Look-out SIR!

- Results?
 - The effect of capacitance



Look-out SIR!


- Results?
 - The effect of capacitance with 2 alternative suppliers



Look-out SIR!


SIR Testing - Limitations:

- It requires skilled operators
- Requires dedicated equipment
- Takes a long time - not less than 72 hours
- Expensive - but what price failure?



SIR Testing - Advantages:

- Determines the effects of both ionic & non-ionic contamination
- Demonstrates the electro-chemical compatibility between ALL process materials
- Can be used to monitor material trends



Association Connecting Electronics Industries




CANON COMMUNICATIONS LLC



Look-out SIR!

SIR Testing - Advantages:


- A quantitative not a qualitative test method
- Works in conjunction with ROSE / SEC
- Predicts whether your end product will be electro-chemically reliable



Look-out SIR!

To summarize by recommendation:

- Decide on your preferred process material mix and run SIR qualification tests
- Analyze any failures using IC or FTIR
- Use ROSE / SEC tests to maintain the process
- Use SIR to monitor material quality by trend



Association Connecting Electronics Industries