

2215 Sanders Road Northbrook, IL 60062-6135

IPC-TM-650 TEST METHODS MANUAL

1.0 Scope The test specifies a standard procedure for determining the viscosity of solder paste in the range of 300,000 to 1,600,000 centipoise.

2.0 Applicable Documents None

- **3.0 Test Specimen** Paste to be tested shall be stabilized at $25^{\circ}\text{C} \pm 1^{\circ}\text{C}$ for a minimum of 24 hours prior to testing. The paste volume shall be sufficient to fill the viscometer receptacle to about 60% of its depth.
- **4.0 Equipment/Apparatus** The equipment used shall be a spiral pump viscometer (Malcom, Brookfield Viscometer or Rheometer with Spiral Adaptor accessory, or equivalent). Set the instrument rotational speed for 10 rpm. Other equipment may be used provided the results can be empirically correlated as mutually agreed upon. Additional shear rates may be specified by the user or supplier.

5.0 Procedure

5.1 Preparation

- **5.1.1** Open the container(s), remove any internal cover, scrape off paste adhering to the lids or internal cover(s) and the container wall(s) and add this to the paste in the container(s).
- **5.1.2** Using a spatula, stir the paste gently for 1 to 2 minutes to homogenize it, taking care to avoid the introduction of air.
- **5.1.3** Transfer sufficient paste to the viscometer receptacle to fill this to about 60% of its depth. Place the receptacle in the temperature controlled unit of the viscometer and allow it to stabilize at $25 \pm 0.25^{\circ}$ C for 15 minutes minimum.

5.2 Test

5.2.1 Immerse the instrument sensor into the sample in accordance with the equipment manufacturer's instructions. The solder paste should not cover the pump outlet.

Number				
2.4.34.2				
Subject				
Solder Paste Viscosity—Spiral Pump Method				
(Applicable for 300,000 to 1,600,000 Centipoise)				
Date	Revision			
1/95				
Originating Task Group Solder Paste Task Group	(5-24b)			
<u> </u>				

- **5.2.2** Turn on chart recorder and set instrument to run at one specific shear rate. Take reading when output has been stable for at least 1 minute. If additional shear rates are to be measured, adjust the speed vernier and repeat above.
- **5.2.3** Record the viscosity measured at the single shear rate value. By mutual agreement between user and supplier multiple shear rates must be used to develop the solder paste shear sensitivity factor.
- **5.3 Evaluation** Enter data in Table 1 "Test Report on Solder Paste."

6.0 Notes

6.1 Test Equipment Sources The equipment sources described below represent those currently known to the industry. Users of this test method are urged to submit additional source names as they become available, so that this list can be kept as current as possible.

6.1.1 Spiral Pump Viscometer Equipment

Brookfield Engineering Laboratories, Inc. 11 Commerce Boulevard Middleboro, MA 02346 USA (800) 628-8139

Malcom Instruments Corp. 26226 Industrial Blvd. Hayward, CA 94545 (510) 293-0580 (510) 293-0584 - fax

6.2 Shear sensitivity factor is defined as the absolute value of the slope of a graph of the log viscosity versus log rpm.

IPC-TM-650					
Number	Subject	Date			
2.4.34.2	Solder Paste Viscosity—Spiral Pump Method (Applicable for 300,000 to 1,600,000 Centipoise)	1/95			
Revision					

Table 1 Test Report on Solder Paste

Enter appropriate information in top portion of report and complete report by entering the test results or checkmarks in the appropriate spaces.					
Inspection Purpose:	QPL I.D. Number:				
Qualification	Manufacturer's Identification:				
Quality Conformance A	Manufacturer's Batch Number:				
Quality Conformance B	Date of Manufacture:				
Shalf Life Extension	Original Use By Dote:				

__ Shelf-Life Extension Original Use-By Date: ______ Performance Revised Use-By Date: ______ Overall Results: __ Pass __ Fail

Inspection Performed by: _____ Witnessed by: _____

	User's Actual			
Inspections	Requirement	Test Result	P/F (*)	Tested by & Date
Material				
Visual				
Metal Content				
Viscosity				
Solder Ball				
Slump				
Alloy				
Flux				
Powder Size				
% In Top Screen				
% In Next Screen				
% In Bottom Screen				
% In Receiver Bottom				
Max. Powder Size				
Powder Shape				
Tack				
Wetting				

^{*} P/F = PASS/FAIL; enter P if test results are within tolerance of actual requirement; otherwise, enter F