

PAD CRATERING THE INVISIBLE THREAT TO THE ELECTRONICS INDUSTRY

Presented by Chris Hunrath

VP of Technology Integral Technology Lake Forest, California



What is Pad Cratering?

- IPC-9708
 - 1.2.4 Pad Cratering "The formation of a cohesive (or adhesive) dielectric crack or fracture underneath the pad of a surface mount component, most commonly BGA packages."







Pad Craters





Pad Cratering... Opens Circuits

- This occurs when the resin crack (fracture) migrates through a copper trace or via.
- This happens at assembly, in service or during handling.

TPS

PO[•] 2012

- When component is removed, PCB copper pad comes with it, leaving behind a "crater" in the PCB.
- Has become more prevalent with lead free assemblies.
- Contributing factors include board thickness, size, resin type, CTE of the PCB and component, solder type, component position, assembly conditions post assembly handling.



How is the Electronics Industry dealing with this Defect Mode?

- Epoxy filets (mounds) at the corner of the BGAs,
- Increased pad or trace widths (Increase in pitch).
- Change trace path.
- Increased board thicknesses.

These fixes are counter to the need to increase board density.

What does this have in common with a Pad Cratering solution?

TPS

PO" 2012 ON

IPC



• Filed April 12, 1934 US Patent 2,109,329



Film Based Materials

- Adding films in specific layers creates opportunities for unique structural benefits. Traditionally, this is done for;
 - Electrical properties
 - Rigid-flex
- Taking the cure process out of the PCB shop opens up the use of different materials.
- May be tailored to the following;
 - Low neat resin CTE while still remaining resilient
 - High Tg and Tg while being halogen free



Material developments that are addressing Pad Cratering

TPS

CAN

PO" 2012

IPC

Higher modulus than flex material, yet more flexible than standard rigid materials (see below).



A pad crater resistant structure may be built using a fracture-resistant film on the surface layer. This <u>resilient</u> layer is in direct contact with the copper pad, preventing fractures from starting or reaching the copper trace or via.

Tp



PO^{**} 2012







- When used as a cap layer (see below) it becomes the interface between the copper pad and the rest of the PCB.
- The more pliant cap will prevent or block fractures and protect copper connections (traces) to the pad.





Examples of Fractures



APEX EXPO" 2012 CANI TPS





Fracture Barrier





As technology advances. . .

Pad Cratering will continue to challenge the industry.

Grater demand for density, reliability and signal performance, while complying with Lead free and halogen free increases the challenge.

Improved thermal performance often comes with lower flexibility.

High performance films used as a fracture barrier allowing current materials to perform better under mechanical stress.

Film based materials offer other benefits:

- Can be used alone or with more traditional glass based materials.
- Controlled Dielectric Spacing without fiberglass.
 - C stage/B stage combinations
- Better Breakdown Voltage performance.

TPS

PO" 2012 CAN

- Improved transmission line performance (DK, Df) without glass reinforcement.
- Film based materials taken beyond flex for improved reliability, density and electrical performance.